



















-  Fire Blanket
  -  Smoke Detector
  -  Heat Detector
  -  Warning Device Bell
  -  Warning Device Sounder
  -  Portable Water Extinguisher
  -  Portable Foam Extinguisher
  -  Portable CO2 Extinguisher
  -  Portable Dry Powder Extinguisher
  -  Emergency Light
  -  Call Point
  -  Warning Device Visual
  -  Fire Exit Directional Signage
  -  Roof Void Smoke Detector
  -  Emergency Exit Illuminated Sign
  -  Fire Control Panel
  -  Fire Exit
- All Fire Exits Have A Push Bar with Fire Exit & Fire Notice Action Signage*



This page is intentionally left blank